

## IMPORTANT INSTRUCTIONS

For 12721GR IRONMAN Shock Absorber



- 1) Spare brake hose bracket on this shock absorber must be bent back at time of installation to provide sufficient clearance to the brake hose.

Failure to do so may cause the brake hose to contact this bracket during operation resulting in damage or loss of brake control.

- 2) This Ironman Shock Absorber can be installed on either side of the vehicle, the ABS Wire Bracket can be bolted in either direction depending on which side the shock absorber is installed.

